

LITECEIVER



Instant Flags - Safer Racing - Fully Encrypted

*This device is an enhancement to and not intended as a replacement of actual human flagging or other existing warning systems



866-301-7223

www.raceceiver.com



Thank you for your purchase

The LITEceiver provides instant flag status all around the track.

Avoid prolonged exposure to direct sunlight



Do Not Overcharge

Battery must be charged every 6 months



Channel must be set to receive flags!

Power/PWR - LED

- Press and Hold PWR to turn on or connect power cable
- Battery LED - Green/Yellow/Red = charge level
- Battery LED Flashes when charging

Brightness

- Press Up/Down to change brightness
- 8 Levels are available
- Wait 3 Seconds to confirm brightness

Channel/CH

- Press CH to show current channel
- Press CH then Up/Down to change (1-5)
- Wait 3 Seconds to confirm channel

Last Flag/Power Off

- Press PWR to see the Last Flag/Battery level
- Press PWR and HOLD for 8 secs to turn off
- Auto powers down after 2 hours idle

